

## EB233 - Eddie Bauer® Sherpa Fleece Full Zip Ladies' Jacket

GARMENT MEASUREMENTS								
Size	XS	S	M	L	XL	2XL	3XL	4XL
<b>Chest - Half Measure</b>	17 1/2"	18 1/2"	19 1/2"	21"	22 1/2"	24"	26"	28"
<b>Chest - Full Measure</b>	35"	37"	39"	42"	45"	49"	52"	56"
<b>Body Length from HPS</b>	25"	25 1/2"	26"	27"	28"	29"	29 1/2"	30"
<b>Sleeve Length-CB</b>	32"	32 1/2"	33"	33 3/4"	34 1/2"	35 1/4"	35 3/4"	36 1/4"

*Finished measurements in inches. Refer to "How to Measure" guide for detailed information on measurement instructions.*

LADIES' General Sizing Guide								
Size	XS	S	M	L	XL	2XL	3XL	4XL
<b>Numeric Size</b>	2	4-6	8-10	12-14	16	18-20	22	24
<b>Bust</b>	32"-34"	35"-36"	37"-38"	39"-41"	42"-44"	45"-47"	48"-51"	52"-55"
<b>Waist</b>	24"-25"	26"-27"	28"-30"	30" -32"	33"-35"	36"-38"	40"-42"	42"-44"
<b>Hip</b>	33"-35"	35"-37"	37"-39"	39"-41"	42"-44"	45"-47"	48"-50"	50"-52"
<b>Sleeve Length - CB</b>	30"-30 1/2"	30 1/2"-31"	31 1/2"-32"	32 1/2"-33"	33 1/2"-34"	34"-34 1/2"	34 1/2"-35"	34 1/2"-35"

