

EB530 - Eddie Bauer® Soft Shell Jacket

GARMENT MEASUREMENTS

Size	XS	S	M	L	XL	2XL	3XL	4XL
Chest - Half Measure	19 1/2"	21"	22 1/2"	24"	25 1/2"	27"	29"	31"
Chest - Full Measure	39"	42"	45"	48"	51"	54"	58"	62"
Body Length from HPS(at front)	25"	26"	27"	28"	29"	30"	30 1/2"	31"
Body Length from HPS(at back)	26 1/2"	27 1/2"	28 1/2"	29 1/2"	30 1/2"	31 1/2"	32"	32 1/4"
Sleeve Length from Armhole Seam	26"	26 1/2"	27"	27 1/2"	28"	28 1/2"	28 3/4"	29"

Finished measurements in inches. Refer to "How to Measure" guide for detailed information on measurement instructions.

ADULT General Sizing Guide

Size	XS	S	M	L	XL	2XL	3XL	4XL
Chest	30"-32"	34"-36"	38"-40"	42"-44"	46"-48"	50"-52"	54"-55"	56"-57"
Waist	26"-29"	29"-32"	32"-35"	35"-38"	38"-41"	41"-44"	44"-47"	47"-50"
Sleeve Length-CB	31"-32"	32"-33 1/2"	34"-35"	35"-36"	36"-37"	37"-38"	38"-39"	38 1/2"-39"

