

EB533 - Eddie Bauer® Ladies' Shaded Crosshatch Soft Shell Jacket

GARMENT MEASUREMENTS

Size	XS	S	M	L	XL	2XL	3XL	4XL
Chest - Half Measure	18 1/4"	19 1/4"	20 1/4"	21 3/4"	23 1/4"	24 3/4"	26 3/4"	28 3/4"
Chest - Full Measure	36 1/2"	38 1/2"	40 1/2"	43 1/2"	46 1/2"	49 1/2"	53 1/2"	57 1/2"
Body Length from HPS	25 1/2"	26"	26 1/2"	27 1/2"	28 1/2"	29 1/2"	30"	30 1/2"
Sleeve Length-CB	32"	32 1/2"	33"	33 3/4"	34 1/2"	35 1/4"	35 3/4"	36 1/4"

Finished measurements in inches. Refer to "How to Measure" guide for detailed information on measurement instructions.

LADIES' General Sizing Guide

Size	XS	S	M	L	XL	2XL	3XL	4XL
Numeric Size	2	4-6	8-10	12-14	16	18-20	22	24
Bust	32"-34"	35"-36"	37"-38"	39"-41"	42"-44"	45"-47"	48"-51"	52"-55"
Waist	24"-25"	26"-27"	28"-30"	30"-32"	33"-35"	36"-38"	40"-42"	42"-44"
Hip	33"-35"	35"-37"	37"-39"	39"-41"	42"-44"	45"-47"	48"-50"	50"-52"
Sleeve Length - CB	30"-30 1/2"	30 1/2"-31"	31 1/2"-32"	32 1/2"-33"	33 1/2"-34"	34"-34 1/2"	34 1/2"-35"	34 1/2"-35"

